



INSTALLATION INSTRUCTIONS

PART No. 30404-30435

MODEL No.

Place the rear corner guard in place and align the bottom edge of the guard with the body tub. Mark the two mounting holes with a magic marker. Center punch the mark, then drill with a small drill bit. Re-drill the holes using an 11/32" drill bit. Bolt the corner guards in place using the stainless steel bolts provided.

TOOLS REQUIRED

Electric drill
Assorted drill bits
.5" Wrench or .5" Socket and ratchet
Hammer and center punch



INSTALLATION INSTRUCTIONS

PART No. 30404-30435

MODEL No.

Place the rear corner guard in place and align the bottom edge of the guard with the body tub. Mark the two mounting holes with a magic marker. Center punch the mark, then drill with a small drill bit. Re-drill the holes using an 11/32" drill bit. Bolt the corner guards in place using the stainless steel bolts provided.

TOOLS REQUIRED

Electric drill
Assorted drill bits
.5" Wrench or .5" Socket and ratchet
Hammer and center punch

