



INSTALLATION INSTRUCTIONS

PART No. 30527 & 20507

MODEL No.

Rear Bumper Bracket



Measure and mark the rear cross member holes centered at 31 7/8". Place the rear bumper brackets on the rear cross member, and fasten using the 3/8" stainless steel bolts provided. Place the front bumper 30436 or 30437 on the brackets and fasten using the stainless bolts provided.



INSTALLATION INSTRUCTIONS

PART No. 30527 & 20507

MODEL No.

Rear Bumper Bracket



Measure and mark the rear cross member holes centered at 31 7/8". Place the rear bumper brackets on the rear cross member, and fasten using the 3/8" stainless steel bolts provided. Place the front bumper 30436 or 30437 on the brackets and fasten using the stainless bolts provided.