



TYGER®

STAR STRIDER®

TG-SR2C74988

Scan to Download the
Latest Digital Version



BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

TORQUE VALUES


Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

- | | | |
|---|--|-----------------------------------|
| x1 Driver Side Star Strider D | x1 Bracket [C] | x26 8mm x 24mm x 2mm Flat Washers |
| x1 Passenger Side Star Strider P | x1 Passenger Side Support Bracket [D] | x13 8mm Lock Washers |
| x3 Bracket [A] | x13 8mm Nylon Lock Nut | x11 8mm Clip Nuts |
| x2 Bracket [B] | x13 8-1.25mm x 25mm Hex Bolts | x6 8mm Double Bolt Plates |



Parts List

Top View


ATTENTION: Refer to **D** and **P** labelling on the side of the tubes to determine Driver and Passenger Star Striders




Reference the letters printed on the brackets to determine mounting locations



Bottom View





TOOLS REQUIRED



STEP I MOUNTING BRACKETS

Follow (Fig 1-20) to attach the brackets to the Passenger Side. (Fig 2-5) are related to models with a DEF Tank.




(Fig 1) Passenger/Right side (3) mounting locations




Passenger-side Front Mounting Area


Note: Skip to **PAGE 4** if your vehicle does not have a DEF Tank




(Fig 2) For model years 2007-2016, remove (3) hex bolts underneath vehicle to remove DEF tank cover



(Fig 3) For model years 2017-2019, remove (4) hex bolts to remove plastic DEF cover










(Fig 4) Removed Passenger Side DEF cover cover






(Fig 5) Models 2007-2016 continue by removing (2) hex bolts to remove tank straps

Verify which type of rocker panel configuration your vehicle has to see if **CLIP NUTS** are necessary (Fig 6-8).



	UPPER PANEL	PINCH WELD
Config 1 (Fig 6)	with threaded insert	with welded nuts
Config 2 (Fig 7)	with threaded insert	flat tab with hole
Config 3 (Fig 8)	no threaded insert	flat tab with hole




Passenger-side Center Mounting Area







Note: For 2017-2018 2500/3500 owners with DEF tank, continue with (Figs 16 – 17). Otherwise, skip to (Fig 18).




Passenger-side Rear Mounting Area






STEP 2 MOUNTING RUNNING BOARDS

Follow (Figs 21-22) to install the passenger-side running board. Then, If equipped, reinstall the trimmed DEF cover (Fig 17) to your vehicle.






STEP 3 DRIVER SIDE

Repeat **STEPS 1-2** for driver side installation.
Front: Use Bracket **[A]** instead of **[C]** & **[D]**;
Center: Use Bracket **[A]** instead of **[B]**;
Rear: Use Bracket **[B]** instead of **[A]**.







Driver-side Front & Center Mounting Area



Driver-side Rear Mounting Area



STEP 4

Installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

