

STEP BARS

TG-SS2T35218


BEFORE INSTALLATION

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF MISSING PARTS OR ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. TO FILE YOUR CLAIM, PLEASE VISIT: WWW.TYGERAUTO.COM/CONTACT

TORQUE VALUES

Fastener Size	Class 8.8 Torque (ft-lbs)	Class 10.9 Torque (ft-lbs)
6mm	6-7	6-7
8mm	15-16	22-23
10mm	31-32	44-45
12mm	54-55	78-79
14mm	87-88	125-126

Parsenger/Right Tyger Rider Driver/Left Tyger Rider Passenger/Right Tyger Rider Driver/Left Front Mounting Bracket Driver/Left Center Mounting Bracket Driver/Left Center Mounting Bracket Passenger/Right Center Mounting Bracket 8-1.25mm x 30mm Hex Bolts 8-1.25mm x 25mm Combo Hex Bolts 8mm Lock Washers 8mm x 24mm OD x 2mm Flat Washers






STEP |

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY. ASSISTANCE IS HIGHLY RECOMMENDED.



Starting on the Driver/Left side of the vehicle, remove any plastic plugs or hex bolts from the factory mounting locations along the bottom of the floor (Figs 1 & 2). The Sidebar will mount to the front and rear locations.


Driver/Left Side Installation Pictured





Select the Driver/Left Front Mounting Bracket. Attach the bracket to the front location with (2) 8mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers (Figs 3 & 4). DO NOT tighten hardware at this time.

Driver/Left Side Installation Pictured




Customer Support: www.TygerAuto.com/Contact



STEP 4

Move to the rear location. Select the Driver/Left Rear Mounting Bracket. Repeat **STEP 3** to attach the Bracket to the rear location (Figs 5 & 6).

Driver/Left Side Installation Pictured





STEP 5

Select the Driver/Left Tyger Rider. Carefully place Sidebar on the brackets.

IMPORTANT: DO NOT slide or rotate Sidebar on cradles, or damage to the finish may result. Attach Sidebar to the Mounting Brackets with (4) 8mm Combo Bolts (Figs 7 & 8). DO NOT tighten hardware.

Driver/Left Side Installation Pictured





Customer Support: www.TygerAuto.com/Contact





Level and adjust the Sidebar and tighten all hardware.



Repeat STEPS 2-6 to attach the Passenger/Right Tyger Rider.

STEP 8

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

Customer Support: www.TygerAuto.com/Contact