



RUST BUSTER

F R A M E W O R K S

RB8412L & RB8412R
1998-2002 Toyota® 4Runner
Mid Section



VIDEO AVAILABLE



REQUIRED TOOLS

Jack Stands or Lift
Mig Welder
Paint/Primer
C-Clamp
Hand Grinder
Cutting Wheel or Torch
Welding Gloves
Welding Hood/Shield
Ear & Eye Protection
Sockets & Ratchet
Fire Extinguisher

KIT CONTAINS

Mid Section
M14 Washer
M14 Hex Screw
M14 Flange Locknut

QTY

1
1
1
1



RUST BUSTER

F R A M E W O R K S

RB8412L & RB8412R 1998-2002 Toyota® 4Runner Mid Section

1) PREPARING YOUR VEHICLE

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

Keep all flammable materials away from the vehicle work area.

2) PREPARING YOUR WORKSTATION

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



RUST BUSTER

F R A M E W O R K S

RB8412L & RB8412R 1998-2002 Toyota® 4Runner Mid Section

3) PREPARING FOR YOUR INSTALL


Remove the lower arm control arm bolt with a 19mm socket.



Hold the part up to the frame and mark off the part's cutline $\frac{3}{4}$ inch from the bottom of the frame.

4) CUT

Begin cutting on the marked line and remove the bottom of the frame, as well as the control arm mount.



Then, grind down the zones free of rust and debris, revealing bare metal.



We recommend painting the part and work area with a weldable primer to help prevent against rust development.



Slide the part into place, using c-clamps as needed.






RUST BUSTER

F R A M E W O R K S

RB8412L & RB8412R 1998-2002 Toyota® 4Runner Mid Section

5) WELD

Remove any potential fire hazards from the work area. Tack weld the part to the frame. Following proper welding procedures, begin welding the part. 100% weld around all edges.



6) PAINT AND PROTECT

If you chose not to protect your part in (Step 4), coat the part and work area with a primer or other rust inhibitor to help prevent or reduce the risk of rust formation.



Then, reinstall the lower control arm bolt with a 19mm socket.