



RUST BUSTER

F R A M E W O R K S

RB8627

2000-2006 Toyota Tundra
Forward Crossmember



REQUIRED TOOLS

Jack Stands or Lift
Paint/Primer
Locking Pliers
Hand Grinder
Cutting Wheel or Torch
Ear & Eye Protection
Sockets & Ratchet
Fire Extinguisher

KIT CONTAINS

Forward Crossmember
M8 Flange Screw
M10 Flanged Hex Screw
M10 Flanged Locknut

QTY

1
2
8
8



RUST BUSTER

F R A M E W O R K S

RB8627

2000-2006 Toyota Tundra
Forward Crossmember

1) PREPARING YOUR VEHICLE

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

Keep all flammable materials away from the vehicle work area.

2) PREPARING YOUR WORKSTATION

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



RUST BUSTER


F R A M E W O R K S

RB8627

2000-2006 Toyota Tundra
Forward Crossmember

3) CUT

Begin burning and punching out the 4 rivets retaining the crossmember to the frame on each side of the vehicle.



Paint the part to help prevent against rust development.



Remove the cross member.

4) INSTALL

Paint the work area with a weldable primer to help prevent against rust development.

Place the crossmember into the frame rails using the rivet holes for help with alignment. Secure the crossmember the included hardware with a 14mm and 17mm socket.