



RUST BUSTER

F R A M E W O R K S

RB7332

88-98 Chevy/GMC K1500/2500
Rear Forward Spare Tire Crossmember Support



REQUIRED TOOLS

Jack Stands or Lift
Mig Welder
Paint/Primer
Locking Pliers
Hand Grinder
Cutting Wheel or Torch
Welding Gloves
Welding Hood/Shield
Ear & Eye Protection
Sockets & Ratchet
Fire Extinguisher

KIT CONTAINS

Crossmember Support
M10 Flanged Bolt
M10 Flange

QTY

1
2
2



**RUST
BUSTER**
F R A M E W O R K S

RB7332

**88-98 Chevy/GMC K1500/2500
Rear Forward Spare Tire Crossmember Support**

1) PREPARING YOUR VEHICLE

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

Keep all flammable materials away from the vehicle work area.

2) PREPARING YOUR WORKSTATION

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



RUST BUSTER

F R A M E W O R K S

RB7332

**88-98 Chevy/GMC K1500/2500
Rear Forward Spare Tire Crossmember Support**

3) PREPARING FOR YOUR INSTALL

Remove your vehicle's bed.



With a 15mm socket, remove the bolts retaining the support to the frame. Followed by removing it the support.



4) INSTALL

With the included hardware and a 13mm and 15mm socket, install your new support.



Followed by painting the work area with a primer to help prevent against further rust development.

